

Assembly instructions - 7ft -

Tools Needed:


- Hammer
- Pneumatic brad nailer (preferred)
- Power drill
- Level
- Power miter saw (preferred)
- $\frac{3}{32}$ " pilot drill
- Nail set
- Wood filler (optional)
- 180 grit sand paper (optional)

Fasteners:

- 1 $\frac{1}{4}$ " finishing nails to fasten cross pieces
- 1 $\frac{1}{4}$ " brad nails if using pneumatic brad nailer
- #8x1 $\frac{1}{4}$ " screws to attach to other modules
- #8x3" screws for attaching racks to wall


Tips:

1. Using pneumatic brad nailer will make assembly quicker and easier.
2. Before opening any boxes, if multiple units and different units have been ordered, please assemble all boxes by units to ensure that specific unit parts are not intermixed with other units.
3. It is highly recommended to drill $\frac{3}{32}$ " dia pilot holes on back cross pieces for #8x3" screws before attaching to wall.




Part list:


(1 pc) Left end ladder 87 $\frac{3}{16}$ "





(1 pc) Right end ladder 87 $\frac{3}{16}$ "



(14 pcs) Spacer





(13 pcs) Cross piece



Step 1

Attaching cross pieces and spacers to the **BACK**.

Place the right and left end ladders on the floor. Nail the cross pieces on the 2nd, 3rd, 4th, 5th, 6th, 7th and 8th support cleat starting from the bottom. Nail spacers on the 1st and 9th support cleat as shown.



Install spacers on 1st and 7th support cleat as shown

Install cross pieces on support cleats as shown

Step 2

Attaching middle spacers.

Place each spacer into middle support cleat slots and nail from the outside.

